

Москва (495)268-04-70	Иркутск (395)279-98-46	Новокузнецк (3843)20-46-81	Смоленск (4812)29-41-54
Архангельск (8182)63-90-72	Казань (843)206-01-48	Новосибирск (383)227-86-73	Сочи (862)225-72-31
Астана (7172)727-132	Калининград (4012)72-03-81	Омск (3812)21-46-40	Ставрополь (8652)20-65-13
Астрахань (8512)99-46-04	Калуга (4842)92-23-67	Орел (4862)44-53-42	Сургут (3462)77-98-35
Барнаул (3852)73-04-60	Кемерово (3842)65-04-62	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Белгород (4722)40-23-64	Киров (8332)68-02-04	Пенза (8412)22-31-16	Томск (3822)98-41-53
Брянск (4832)59-03-52	Краснодар (861)203-40-90	Пермь (342)205-81-47	Тула (4872)74-02-29
Владивосток (423)249-28-31	Красноярск (391)204-63-61	Ростов-на-Дону (863)308-18-15	Тюмень (3452)66-21-18
Волгоград (844)278-03-48	Курск (4712)77-13-04	Рязань (4912)46-61-64	Ульяновск (8422)24-23-59
Вологда (8172)26-41-59	Липецк (4742)52-20-81	Самара (846)206-03-16	Уфа (347)229-48-12
Воронеж (473)204-51-73	Магнитогорск (3519)55-03-13	Санкт-Петербург (812)309-46-40	Хабаровск (4212)92-98-04
Екатеринбург (343)384-55-89	Мурманск (8152)59-64-93	Саратов (845)249-38-78	Челябинск (351)202-03-61
Иваново (4932)77-34-06	Набережные Челны (8552)20-53-41	Севастополь (8692)22-31-93	Череповец (8202)49-02-64
Ижевск (3412)26-03-58	Нижний Новгород (831)429-08-12	Симферополь (3652)67-13-56	Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47 Казахстан (7273)495-231 Таджикистан (992)427-82-92-69

Единый адрес для всех регионов: aga@nt-rt.ru || <https://amgo.nt-rt.ru>

4-Post Lift Accessories

JACK TRAY FOR 4 POST PARKING LIFT

Optional jack tray for four-post parking lift. Kits No.:



410040 (A435-P) Kits No.: 410062 (A440-P, A440-HP)

PLASTIC OIL TRAY FOR 4 POST PARKING LIFT

Optional plastic oil tray for 4 post parking lift. Kits No.:



410140 (A435-P) Kits No.: 410141 (A440-P, A440-HP)

ALUMINUM ALLOY DRIVE-IN RAMPS FOR 4 POST PARKING LIFT

Aluminum alloy drive-in ramps Weight for one set (2 pcs) only 18kg Kits No.40803



EXTENSION PLATFORM

Platform extended to 610mm with extension kit



90° INSTALLING PLATE FOR 4 POST PARKING LIFT



90° installing plate for installing power unit at the side of column. Kits No.40802

CASTER KITS FOR 4 POST PARKING LIFT



Optional Caster Kits for moving the parking lift easily .Kits No.40801

AIRLINE KITS FOR 4-POST LIFTS



Optional airline kits. Easy and convenient to install with all models of rolling jack with pneumatic pump. Kits No.:40102

TURNPLATE



For 4-post lifts and professional alignment Scissors lifts For four-wheel positioning to simulate the wheel rotation test.

Москва (495)268-04-70
Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58

Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Казахстан (7273)495-231

Таджикистан (992)427-82-92-69

Единый адрес для всех регионов: aga@nt-rt.ru || <https://amgo.nt-rt.ru>